




NOTE: Repeat for all four arches






NOTE: Repeat for the opposite side




NOTE: Repeat for the opposite side










NOTE: Repeat for the opposite side







































Parts may need careful removal from the MDF boards with a scalpel, and light sanding of any rough edges. We recommend testing assembling sections before permanently gluing together.







NOTE: Line up the staircase with the Arcade. Glue not needed.Can fit with other Arcade products

